



Wall Type	Elevation to Story	Height [m]	Thickness [m]	Area [m ²]	Net Volume [m ³]	Perimeter
T Drywall 376mmX2950mm Height	-0,25	3,40	0,35	0,07	0,06	1,39
T Drywall 376mmX4150mm Height	-0,20	4,05	0,37	0,06	0,11	1,22
T Drywall 485mm Garage Roof Upstand Ma...	-0,91	0,30	0,45	0,76	0,17	4,44
T Drywall-40 300mm outer faces only	2,70	1,15	0,08	0,04	0,01	1,10
T Drywall 3150mm Garage	-0,20	3,55	0,35	5,47	11,49	33,72
T Drywall 3150mm Garage	-0,20	3,60	0,35	3,26	2,12	21,43
T Drywall 376mmX4150mm Height	-0,20	4,01	0,35	8,02	14,71	50,00
T Drywall 376mmX4150mm Height	-0,20	4,05	0,35	5,42	11,94	31,80
T Drywall-40 300mm+Insulation	-0,20	4,05	0,35	1,68	5,06	10,40
T Drywall 376mmX4150mm Height	0,10	4,06	0,35	13,72	35,40	94,00
T Drywall-40 300mm+Insulation	0,10	4,25	0,35	3,07	6,17	20,47
T Drywall 485mm Garage Roof Upstand Ma...	-0,91	0,30	0,45	10,50	2,49	52,41
T Drywall-01 147-OSB	0,10	3,75	0,15	1,10	3,23	16,26

This is a view of a Wall Schedule. I have closed the view and after reopening it I got this. The fill here represents the 2D plan preview of the walls but it has spread out all over the schedule. the solution is to disable the 2D plan preview.